

Metric series

3D view



INSUMIND PERÚ
INSUMOS MINEROS INDUSTRIALES

HOW TO ACTIVATE 3D?

To activate the interactive 3D view in Acrobat Reader, you need to select, at the top of the page, **Options** and then **Trust this document**

Zoom

Moves you toward or away from objects in the scene when you drag vertically. You can also zoom with the hand tool by holding down Shift as you drag.

Pan

Moves the model vertically and horizontally only. You can also pan with the hand tool: Ctrl-drag.

Rotate

Turns 3D objects around relative to the screen. How the objects move depends on the starting view, where you start dragging and the direction in which you drag.

Augmented Reality (AR) - Digital meets real


Augmented Reality, often shortened to AR, is a technology that blends digital information into the real world.
For more information, please click here or directly try yourself by scanning the QR code with your phone.

SCAN ME



Metric series

2D derivation



ISO view



INSUMOS MINEROS INDUSTRIALES


Bill-Of-Materials


N°	Description	Amount
1	33112JR	1
1.1	33112JR Inner ring	1
1.2	33112JR Roller	1
1.3	33112JR Outer ring	1



Metric series

Technical drawings





INSUMINO PERÚ
INSUMOS MINEROS INDUSTRIALES



Metric series

Technical data

ORDER (Bearing No)	33112JR
SD (Inside Diameter / mm)	60
D (Outside Diameter / mm)	100
T (Bearing Width / mm)	30.00
B (width / mm)	30.0
C (width / mm)	23.0
R (Radius / mm)	1.5
CR (Basic dynamic load rating / kN)	149
COR (Basic static load rating / kN)	170
CU (Fatigue limit load / kN)	25.9
NG (Limiting speeds (Grease) / rpm)	3700
NO (Limiting speeds (Oil) / rpm)	5000


INSUMIND PERÚ
INSUMOS MINEROS INDUSTRIALES



Metric series

CAD plugins

With our CAD integrations, you can use 3Dfindit directly in your CAD system and make your work easier with additional comfort functions, such as replacing a part and many more.



To the plugins